



8 button membrane SW to OSD Control Board CN2 Pin Assignment	
pin #	description
10	Common Ground
9	Select Up
8	Select Down
7	Adjust Up/Increase/Right
6	Adjust Down/Decrease/Left
5	Menu
4	Brightness Down
3	Brightness Up
2	ON/OFF
1	Common Ground




Membrane Switch:
P/N:356301021



PCB OSD INTERFACE:
P/N:416100101

PCB OSD Control Board CN1 Pin Assignment	
pin #	description
12	no connection
11	OSD Select UP
10	OSD Select Down
9	OSD Plus/Right
8	OSD Minus/Left
7	OSD Menu
6	Ground
5	Backlight Brightness VR pin B
4	Backlight Brightness VR pin WIP
3	Backlight Brightness VR pin A
2	Power Switch B
1	Power Switch A



Cable:
P/N:420680250 (10/12 WAY)
P/N:420680260 (12/12 WAY)
P/N:420680270(12/5&12 WAY)

Digital View

Title:
OSD Control Assembly

NOTE:
All dimensions are in mm

Date:
19.11.98

Ref. No.: OSD GUIDE